

MCU 73650

N 88 - 15927 ^{S3-34}
116625

P24

Ames Research Center Cryogenics Program

Peter Kittel

28 April 1987

Objective:

Develop the cryogenic technology needed for future space missions

Emphasis:

Developing the technology needed for infrared astronomy missions

Current Program:

A two part program

Technology development in support of the SHOOT
(Superfluid Helium On-Orbit Transfer) Project

OAST Sponsored Technology development in support
of future missions generic technologies and on-going
development efforts

Brief History of the Ames Program:

OAST-funded program for more than ten years (started FY 77)

Thrust: Develop the cryogenic technology for space based science

Emphasis: Needs of future IR missions

Selected Accomplishments:

-1g cryogen containment	JTX demo (1.5K)
Superfluid leak sealant	Temperature stabilized ADR (0.2K)
Thermoelectric cooler (80K)	Cryo valve
Self-contained He3 cooler (0.27K)	Ruggedized thermometers
Portable He3 Cooler (0.3K)	-1g He3 Cooler
ADR temperature stability theory	VCS heat exchange model
VCS optimization	O-g He3 design guide
Mini ADR (0.05K)	PODS-III
Pressed contact conductivity	Helium transfer workshop
TAO predictor	Theory of FEP limits
PODS-IV	Orifice pulse tube refrigerator (60K)
Low cavitation helium pump	High Reynolds No. He-II dynamics
He-II flow meter	

SHOOT Program Summary

Joint GSFC/ARC/JSC Program (Overview given in companion presentation)

ARC responsible for selected technologies

Centrifugal pump
Including fluid management device


Flow meter

Friction factor of superfluid helium

EVA
Including transfer line

Data/command system
Including AFD controller

Fluid Management System



ORIGINAL PAGE IS
OF POOR QUALITY.

Centrifugal Pump

Single stage centrifugal pump (flow >800 l/hr, head <170 torr)

Two inducers tested:

6-bladed fan type

Pump cavitates for <300 mm NPSH in superfluid (desired 0 NPSH)

3-bladed screw


Pump cavitates for <100 mm NPSH in superfluid

<-100 mm NPSH in normal fluid



New inducer to be tested:

Jet type (part of pump's output is diverted to the inlet to entrain the fluid)

There is some evidence that the heat flowing from the pump through the screen can cause an additional head rise in the smallest sized screens, due to the thermomechanical effect.



Centrifugal Pump



Flow Meter

Two type tested:

Turbine meter

Repeatable readings in both superfluid and normal fluid helium

Cavitates easily in superfluid helium if backpressure is low

Difficult to cryo rate the small bearings

Gas flow/2-phase flow can over-spin rotor

Not selected


Venturi meter

Repeatable readings

Cavitates easily in superfluid helium if backpressure is low
(at about 0.05 psi below saturation)

Candidate meter to be used with 2 differential pressure guages

venturi meter



Friction Factor of Superfluid Helium

Helium flow test facility:

Flow path: Multiples of 5 m < 20 cm diameter
Temp/pres: 1.5-5 Kelvin svp - 5 bar
Flow rates: < 2500 l/hr

Straight tube results:

At high Reynold numbers (10^4 - 10^6) superfluid helium behaves like a Newtonian fluid

Bellows section results:

Pressure drop approx. 50% greater than predicted


Based on modelling bellows as a series of orifices (a correlation that works for water and for liquid nitrogen)

Planned work:

More tests with bellows

Flow coefficient for valves

Liquid Helium Flow Test Facility



EVA

Purpose:

Demonstrate the human factors associated with helium resupply handling transfer line

Operating coupling

Interface with control/data system

Demonstrate EVA coupling and transfer line

Measure thermal performance before and after coupling operation

Measure flow impedance before and after coupling operation

Procedure:


Launch with coupler mated

Perform several transfer operations

Demate then mate coupling

Perform several more transfer operations

EVA coupler concept



Data/Command System

Approach:

Process control core

Real time data acquisition

Real time control

Manual control

Pre-packaged routines

Growth to full automation

Expert system shell

Fault diagnosis

Valves, sensors, pumps

Growth potential to full up expert system with fault work arounds

OAST Technologies

Storage technologies

PODS

Support materials

Design tools and options

Active coolers

Pulse tubes

Sub-kelvin coolers

Hc-3

ADR


Dilution

2 Kelvin cooler

Passive Orbital Disconnect Struts (PODS)

- Variable strength variable thermoconductance Dewar support system
- High strength on launch
- Low conductance on orbit
- Extensive ground testing (flight ready - chosen for GP-B)
- Best suited for missions where orbital frequency requirement < launch frequency requirement
- Two versions developed**
- PODS-III:** best thermoconductance to strength ratio
- Suited for moderated sized systems
- PODS-IV:** best side load resistance
- Suited for system with many/heavy shields

DEWAR SUPPORT WITH PASSIVE ORBITAL DISCONNECT (PODS)



Support Materials

New materials can improve both strap type and PODS type supports

Want greater strength (ultimate, buckling, fatigue, etc.) to conductance ratio

Glass - Epoxy: Used in IRAS and COBE

Graphite - Epoxy: Better below 30 Kelvin (used in PODS)

Alumina - Epoxy: Under development by various groups

Conductance similar to glass above 30 K

Conductance similar to graphite below 30 K

Ultimate strength similar to glass

Stiffness similar to graphite

Alumina - PEEK (a polymerized ketone) Ames/NBS program

Promises to be better than epoxy (also less permeable to helium diffusion)

Pulse Tubes

Motivation:

Need for low cost, highly reliable, high efficiency coolers (15-100 K)

Pulse tubes:

One moving part (a room temperature compressor with a room temperature seal)

Uses existing G-M and Stirling cryocooler technology
compressors, regenerator

No cold displacer

Phase shift between pressure and velocity waves is supplied by balast volume and orifice

Heat pumping occurs within empty (except for working gas) tube

Heating/cooling is the result of discontinuity of enthalpy flow at ends of tube

Bread-board single stage:

60K min., 16W @ 100K, 50-90% efficient (tube only)

Overall efficiency approaches that of Stirling cycle

Model:


Math model being developed to study optimization of cycle cooling power scales with volume of pulse tube

Future work:

Build demonstration unit

Measure performance at lower temperatures (a second stage)

Pulse tube refrigerator



Sub-Kelvin Coolers

Dilution Refrigeration (300-5 mK)


Uses a $^3\text{He}/^4\text{He}$ mixture

Has become the refrigerator of choice in most ground based applications

Approach

- Develop ^3He circulating type circulating type
- 20 years of commercial experience to draw upon
- Requires the control of 3 fluid interfaces
- Use surface tension devices to control fluid interfaces
- (JPL is trying electrostatic control)
- (MSFC is trying ^4He circulating type)

Dilution refrigerator



Sub-Kelvin Coolers

Adiabatic demagnetization refrigerator (<0.1 Kelvin)
Simplest (gravity independent), closest to being flight ready of all sub-kelvin coolers

Ames has developed two working ADR's with excellent performance
14 μ K stability at 100 mK for 12 hr
Achieves temperatures down to 50 mK
90% duty cycle


Operating principal:

- Magnetization of paramagnetic material (a solid) at 2 Kelvin with 6 Tesla field
- Adiabatic demagnetization to operating temperature
- Isothermal demagnetization to maintain temperature under feedback control
- Repeat

Current activities:

- Efficiency improvement
- Improved refrigerants (ones without water of hydration)

Adiabatic Demagnetization Cooler



2 Kelvin Cooler

Stored cryogens may not meet requirements of long life (<2 years)

Large heat load (>1 W @ 2 K) missions such as LDR

Goal:

Develop a final stage to work off coolers being developed in other NASA/DOD programs


Possible approaches:

Reverse turbo Brayton

Magnetic cycles

Use of ^3He as working fluid

2K Cooling Stage



SPEAKER: PETER KITTEL/AMES RESEARCH CENTER

Mojibul Hasan/Lewis Research Center (Resident Research Associate)

I have a question about your pressure drop. On the straight tube, your pressure drop for helium correlates well with the prediction, however, in the bellows section, the pressure drop was 50 percent greater than predicted. Is this 50 percent over the entire range of flow you tested or only at the higher Reynolds numbers?

Kittel:

We've only made those measurements at the higher Reynolds numbers.

Hasan:

So, you had this inconsistency only at the higher Reynolds numbers; what was the system pressure?

Kittel:

It was near saturation; it was above, but not very much above.